## Arko 130 Freestanding Bath with integrated overflow -

## Important — Read this first!

- 1 Inspect the bath **before installation** to ensure there are no visible defects. If a defect is found, do not install the bath and contact the supplier immediately. Claims for defects will not be accepted after the product has been installed.
- The bath must be installed by a **licensed tradesperson**. 2 Failure to do so may void the warranty.
- Compliance with AS.3740 Waterproofing of Wet Areas 3 within Residential Buildings applies when installing baths.
- 4 Local authorities may have specific installation requirements and this should be checked before installation.
- 5 Grade the **bath sub-floor** in accordance with requirements of local authorities. Grade sub-floor 1:60 minimum.

## Installation notes

- 1 Can be installed using a flexible connector pipe (not supplied).
- Suits 40 mm waste (not supplied). 2
- 3 Use acetic cured silicone sealant. Do not use epoxy type adhesives.
- Always use the actual product to verify placement. 4
- 5 The bath is supplied with four adjustable support feet on the base frame of the bath.
  - Position the bath into place and use the adjustable support feet to ensure that the bath is level. Leave a 3mm void between the base of the bath and the floor.
  - Use silicone around the base, to seal the bath to the floor. Allow a 20mm gap in the silicone seal, to act as a weephole (the gap is designed to reveal any plumbing leakage).

**Warning!** Failure to level the bath correctly may damage the bath structure and cause cracking.





Bath has integrated overflow



Please note

All measurements are in millimetres.

- Dimensions are nominal and subject to normal ceramic manufacturing variations of ±5mm.
- Fixing: Use acetic cured silicone sealant. Do not use epoxy type adhesives.
- Specifications may vary without notice as part of our continuous improvement practices.

bath

floor

- Clean with a damp cloth. Do not use abrasive cleaners, liquids or pastes.

seima.com.au

kitchen + laundry + bathroom ware

Leave a 3mm gap

between base of

seal base of bath

to floor, leaving a 20mm weephole.

bath and floor. Use silicone to