


Chios Care Link Toilet Suite


CHOICE OF CERAMIC OR PLASTIC CISTERN



IMPORTANT


- 1 Inspect the components **before installation** to ensure there are no visible defects. If a defect is found, do not install the toilet suite and contact the supplier immediately. Claims for defects will not be accepted after the product has been installed.
- 2 This wall faced toilet suite is suitable for a variety of set-ups:
CISTERN — accommodates **Bottom Entry Inlet** connection (left or right stop valve).
PAN — accommodates S-trap installation.
- 3 The toilet suite must be installed by a **licensed plumber**. Failure to do so may void the warranty.

CISTERN PACKAGE CONTENTS



CERAMIC CISTERN
comes with flush valve
and Bottom Entry inlet
valve already installed.

OR



PLASTIC CISTERN
comes with flush valve
and Bottom Entry inlet
valve already installed.

1 x ceramic base and lid
with raised flush buttons
containing:

1 x flush valve

1 x bottom entry inlet valve

Cistern is supplied with flush valve
and Bottom Entry inlet valve already
installed. See Diagram A.


1 x plastic base and lid
with raised flush buttons
containing:

1 x flush valve


1 x bottom entry inlet valve

Cistern is supplied with flush
valve and Bottom Entry inlet valve
already installed. See Diagram A.

PAN PACKAGE CONTENTS




1 x ceramic pan



2 x caps (white)
2 x floor screws (+ white plugs)
2 x pan plugs (white)

Optional fixing #2 — used to secure pan to floor.
Plastic plug is placed into hole at base of pan
exterior; screw is rebated into plug. Cap is used
to cover plastic plug.

SEAT PACKAGE CONTENTS



1 x Care toilet seat and fittings

SEIMA

kitchen + laundry + bathroom ware

seima.com.au

Please note

- Installation shall be in accordance with AS/NZS3500.
- All measurements are in millimetres. Height dimensions are to base of pan. Make allowance for bedding.
- Bedding: Pan may be bedded with cement base or using silicone sealant. Fix pan to floor using a sand cement mixture of 3:1 to a depth of 60mm. Do not use lime or fast-drying cement.

- Bracket fixing: The pan should be bedded with silicone sealant and fixed with the brackets supplied.
- Do NOT use epoxy type adhesives.
- Dimensions are nominal and subject to normal ceramic manufacturing variations.
- Specifications may vary without notice as part of our continuous improvement practices.
- Clean with a damp cloth. Do not use abrasive cleaners, liquids or pastes.





DIAGRAM A

BOTTOM ENTRY SET-UP, AS SUPPLIED



Installation guide

1 S-TRAP PROCEDURE — SECURING THE PAN CONNECTOR IN PLACE

Determine the centre of the pan and mark the centre line on the floor and wall.

Work out the setout required. The recommended setout is 300 mm. (Note: Additional setout can be achieved using a 20mm pan connector, not supplied.)

Position the pan connector into the floor outlet pipe (S-trap).

2 POSITIONING THE PAN

Use the centre line marked on the wall and floor to position the pan (see Step 1.1). Push the pan into the installed plastic pan connector. It is recommended that wedges are used to support the foot of the pan during positioning.

3 BOTTOM ENTRY INLET CONNECTION — SET-UP

SEE DIAGRAM A.

The bottom entry inlet valve is already installed on the right side of the cistern. The position can be swapped to the left side if required.

Connect the flexible inlet hose to the stop valve and water control inlet valve on the wall. Leave flexible inlet hose unsecured for now — for the bottom entry inlet connection, the flexible inlet hose will be connected to the cistern's inlet valve (see item 6 on next page).

4 SECURING THE PAN ON THE FLOOR

Cement fixing (optional fixing #1)

Bed the pan with cement bedding, level the pan while the cement mixture is workable. Fix pan to floor using a sand cement mixture of 3:1 to a depth of 60mm. Do not use lime or fast-drying cement.

Important: Allow at least 24 hours for the cement mixture to set before using the toilet.


Screw fixing (optional fixing #2)

Bed the pan with acetic cured silicone sealant, ensuring that the pan is level. Then place the **pan plugs** into the floor fixing holes in the pan and install the **floor screws** into place. The white **caps** can be used to cover the plugs on each side of the pan.


Important: Do not over-tighten the bolts or screws as this may cause the ceramic to crack and break.

Installing the cistern

CERAMIC CISTERN




PLASTIC CISTERN




Installing the flush pipes


- ① Assemble toilet connector pipe with sealing washer and fit cover.




- ② Join the toilet connector pipe to the straight pipe.



- ③ Adjust the distance between the cone washer and the end of the straight pipe.




- ④ Connect the two straight pipes as shown in the diagram.



Installing the seat




SEAT PACKAGE CONTENTS




- ① SEAT
- ② STAINLESS STEEL CAPS (x 2: one for left, one for right)
- ③ STAINLESS STEEL PLATES WITH PIN (x 2: one for left, one for right)
- ④ TOGGLE BOLTS (x 2: one for left, one for right)
- ⑤ PLASTIC BUFFER CAPS (x 2: one for left, one for right)

INSTALLATION




STEP 1

Connect items 2, 3 and 4 together first. Then install them into the holes of the toilet seat.




STEP 2

Put toggle bolts into installation holes of toilet.




STEP 3

Adjust the seat to a good position.




STEP 4

Open the stainless steel cap and tighten the toggle bolts. Then replace the caps.



STEP 5

Adjust the buffers to a good position so that the seat is stable on the rim of the toilet. Then tighten the bolts.



STEP 6

Install the plastic caps on the buffer.